

THERMO MFG.

THERMOFOAM

LOW PRESSURE POLYURETHANE FOAM CLEANER

ThermOfoam Cleaner is a multi-purpose cleaning agent used to dissolve uncured or fresh polyurethane foam and adhesive, formulated without the use of any ozone-depleting materials. ThermOfoam Cleaner is uniquely designed for cleaning the one-component professional dispensing units, as well as for general cleaning purposes such as tools, work surfaces, etc.

APPLICATION AREAS: Typical application for ThermOfoam Cleaner would include cleaning of the one-component dispensing guns to keep internal and external parts working efficiently. It may also be used for dissolving uncured urethane foam and adhesives in most one-component applications.

PROPERTIES: The pre-pressurized cleaning agent dissolves uncured or fresh polyurethane foam and will evaporate quickly.

ThermOfoam Cleaner requires no outside mechanical or electrical power source. Recommended temperature for use is 75°F (24°C). It is available in one size, complete and ready to use, with a collar for attaching to the one-component dispensing unit, and red spray activator for general cleaning purposes.

Its unique design will allow the user to dispense contents in the upright or inverted position for easy access and convenience of use with the one-component dispensing units.

PREPERATION FOR USE: Shake can well before using. For general cleaning purposes, insert the red spray activator onto the valve stem of the can. With arrow pointing towards the surface to be cleaned, slowly depress the red activator to spray cleaning agent. In case of delicate surfaces or fabrics, test a concealed area for evaluation. Wipe off excess residue or rub fabrics if necessary.

APPLICATION/USE: *Dispensing Unit Cleaning:* Follow general cleaning instructions after every can to remove any fresh foam from dispensing unit adapter and barrel opening before attaching new container. It is not necessary to flush the dispensing unit after every can. Always replace the empty product container immediately with a fresh can. To maintain the dispensing unit in good working order, follow these instructions after every 10-20 cans, or prior to repair. While holding red spray activator aside, screw ThermOfoam Cleaner container onto dispensing unit adapter until it will go no further. Do not over tighten. Carefully pull the trigger until solvent extrudes from the gun tip. Release the trigger and let cleaning agent soak in for one to two minutes. Pull trigger and dispense cleaning agent into suitable container. If necessary, repeat procedure two to three times until only clear cleaning agent appears from barrel.

PRODUCT STORAGE: Store in a cool, dry area. Do not expose to open flame or temperatures above 120°F (49°C) to avoid excessive pressure build up. ThermOfoam Cleaner is reusable by following product instructions.

SPECIAL HANDLING: Contents are extremely flammable. Never use near open flame, sparks, heat sources or other potential sources of ignition. Vapors may cause flash fire if ignited. Contents are under pressure. Do no puncture or incinerate. Do not place in hot water or near radiators, stoves or other sources of heat or store above 129°F (49°C).

IMPORTANT NOTE: Cured foam cannot be dissolved with ThermOfoam Cleaner. Do not use pointed or sharp objects for cleaning of dispensing units. Use only in well ventilated areas. Wear impervious gloves, eye protection, and protective clothing when using. Read all instructions and safety information prior to use of any product. **KEEP OUT OF REACH OF CHILDREN.**

THERMO MANUFACTURING INC.

Canton, OH44705 • U.S. & Canada Phone Toll Free: (888) 678-3709 • U.S. & Canada Fax Toll Free: (888) 678-8711 •

www.ThermoPan.com